



N508 BACnet DIGITAL THERMOSTAT 7-DAY PROGRAMMABLE SCHEDULE

VARIABLE AIR VOLUME, MODULATING HEAT • 2-PIPE SYSTEM

Discharge Air Temperature

The Discharge Air Temperature sensor (DAT) provides the controller with the coil leaving air temperature (LAT). This is used to control the proportional heat to achieve a pre-set, but adjustable, discharge temperature. On heating it controls occupant comfort.

SEQUENCE OF OPERATION:

Modulating Heating

On a call for heating, the hot water valve will begin to modulate open. The valve will continue to open until the discharge air temperature reaches 90°F (32°C). Simultaneously, the fan will modulate from minimum airflow to maximum airflow to achieve room set point. Upon a decrease in heating demand, the sequence will reverse.

Deadband

With no demand in the space, there will be no call for heating. The fan will be at a deadband set minimum airflow. The hot water valve will be off.

Notes:

- EZstat is factory programmed for the specific sequence of operation.
- EZstat is also factory calibrated when airflow settings are provided for easy start-up.
- Field commissioning (password protected):
 - Max. and Min. airflow settings are field adjustable between the ranges on the unit's ECM fan curve calibration chart.
 - Deadband differential and other parameters are also adjustable.
 - Refer to EZstat Application Guide/IOM.
- Remote mounted 24 VAC thermostat is field wired (by others). Refer to application specific wiring diagram.
- Thermostats baseplate mounts to a standard 2" (51) x 4" (102) vertical handy box.



SCHEDULE TYPE:

PROJECT:

ENGINEER:

CONTRACTOR:

Dimension are in inches (mm).

DATE	B SERIES	SUPERSEDES	DRAWING NO.
9 - 23 - 14	FCS	NEW	FCS-N508-2